


Aqua Silentia Instrument Panel



- No1 / No1 Battery bank voltage meter should read 12volt. Then when engine running 13.5 volt
- No2 / No1 Battery bank Amp meter (should read + amps when engine running)
- No3 / Engine temperature should read 70deg normal running (after 30 mins running)
- No4 / No2 Battery bank Amp meter (should read + amps when engine running)
- No5 / No2 Battery bank voltage meter should read 12volt. Then when engine running 13.5 volt
- No6 / Gear box oil pressure should read 150 psi when engine running
- No7 / Ignition light. Is on when ignition switch is turned on and goes off when engine is running
- No8 / Low cooling water pressure audible alarm
(will sound when ignition switch is on then stop when engine running)
- No9 / Not in use
- No10/ Engine oil pressure should read 50 psi when engine running
- No11/ Ignition switch (turn right to switch ignition on then continue to turn to start the engine)
- No12/ Rev counter Maximum continuous engine rating 2000 rpm
- No13/ Not in use
- No14 Pull to stop engine (when engine stopped turn off ignition switch turn to the left)